

# Printing from Multisim

Type ctrl-p (control-P) in the schematic or waveform window

You can then send it to [pdf](#) or [follow-you-printing](#)