Last updated 7/25/25


- Declaration Full Structure
  - This applies to variables and functions
  - Declarations consist of 4 elements
    - Storage Class
    - Type Qualifier
    - Type Specifier
    - Declarator
  - Format
    - (Storage\_Class) (Type\_Qualifier) Type\_Specifier Declarator;
       int foo;
      - () indicates optional

#### Storage Class

- The storage class determines the duration of a variable's existence – it's scope
- Storage class dictates where the variable is stored in data memory
- Storage class determines where the variable can be seen
  - no linkage only visible in the current block {}
  - internal linkage visible in the current file
  - external linkage visible in more than one file
- 4 storage classes
  - Auto
  - Static
  - Extern
  - Register


- Storage Class Auto
  - Default value if not specified
  - Variable exists until the end of the block {} (scope) in which it was declared
    - Once the block is completed the variable no longer exists
  - Only visible in the current file (no linkage)
  - Stored in the Stack
  - Auto is typically omitted since it is the default

auto int foo;  $\leftrightarrow$  int foo;



- Storage Class Static
  - Variable exists in the block {} in which it was declared for the duration of the program
    - Commonly used in functions to retain the variable's value between calls (e.g. a counter) – (no linkage)
    - Global variables are static
    - Only visible in the current file (internal linkage)
    - Can be initialized at the same time it is declared
- One of two exceptions to our prescribed declaration format
  - If un-initialized or initialized to 0 stored in the BSS segment
  - If initialized (not 0) stored in the Data segment

static int foo = 5; static int boo;



ELE 1610 5

- Storage Class Extern
  - Variable visible in more than one file (external linkage)
    - Used when multiple files need access to a single variable
    - Defined in 1 file, declared as extern in any files that want to access
      it
    - Has a Static duration
    - Stored in the Data segment
    - If it needs to be initialized, it should be done at the same time it is defined ensures all files see the initialization


```
File 1

File 2,3,...

int foo;
int loo = 3;
int boo[10]


extern int loo;
extern int boo[]

note - no size here
```




- Storage Class Register
  - Variable stored in a CPU register
    - Allows fast access
    - Only defined with-in a block {}
    - Only visible in the current block (no linkage)
    - Not used often due to high quality compilers used today
    - The compiler can ignore this request

register int foo;



ELE 1610 7 ©

Data Memory



ELE 1610